

ESPRINT

PROGRAMMING SHEET

SOFTWARE VERSION 1.10

PROGRAMMER CODE: (default: 747474)

(Addresses 000 to 002)

Important: Use only numeric keys from [1] to [10] to enter programmer code. (Key [10] = 0.)

000: ___/___ **001:** ___/___ **002:** ___/___

PGM OUTPUT:

Values entered at address **003-005** contain 2 digits.

003: ___/___

PGM TYPE

004: ___/___

PGM (1st, 2nd digit)

005: ___/___

PGM (3rd, 4th digit)

KEYPAD TROUBLE DISPLAY

The trouble code list is shown in the following table:

[2] Printer Offline	[9] Esprint Date Loss
[3] Paper Empty	[10] Serial Input Cable Loss
[5] Printer Fault	[11] Fail to comm. (serial)
[6] Printer Busy	[12] Fail to comm. (parallel)
[8] Esprint Timer Loss	

ESPRINT OPTIONS

006:		KEY OFF / ON	
<input type="checkbox"/> N/A	<input type="checkbox"/> [2ND]	<input type="checkbox"/> N/A	
<input type="checkbox"/> N/A	<input type="checkbox"/> [1]	<input type="checkbox"/> N/A	
Paper offline enabled	<input type="checkbox"/> [2]	<input type="checkbox"/> Paper offline disabled	
Paper empty enabled	<input type="checkbox"/> [3]	<input type="checkbox"/> Paper empty disabled	
<input type="checkbox"/> N/A	<input type="checkbox"/> [TRBL]	<input type="checkbox"/> N/A	
<input type="checkbox"/> N/A	<input type="checkbox"/> [4]	<input type="checkbox"/> N/A	
Printer fault enabled	<input type="checkbox"/> [5]	<input type="checkbox"/> Printer fault disabled	
Printer Busy enabled	<input type="checkbox"/> [6]	<input type="checkbox"/> Printer Busy disabled	
		KEY OFF / ON	
Zone 12 burglar ⁽¹⁾	<input type="checkbox"/> [MEM]	<input type="checkbox"/> Zone 12 fire ⁽¹⁾	
Serial output disabled	<input type="checkbox"/> [7]	<input type="checkbox"/> Serial output enabled	
Parallel output disabled	<input type="checkbox"/> [8]	<input type="checkbox"/> Parallel output enabled	
Event list 2 ⁽³⁾	<input type="checkbox"/> [9]	<input type="checkbox"/> Event list 1 ⁽²⁾	
Clock refreshed by panel	<input type="checkbox"/> [BYP]	<input type="checkbox"/> Clock runs independently	
Event list 3 ⁽⁴⁾	<input type="checkbox"/> [10]	<input type="checkbox"/> Event list 1 or 2	
Zone 3 burglar ⁽⁵⁾	<input type="checkbox"/> [11]	<input type="checkbox"/> Zone 3 fire ⁽⁵⁾	
Partitionning disabled	<input type="checkbox"/> [12]	<input type="checkbox"/> Partitionning enabled	

Note:
 (1) For 738 / 748 version 0.97B
 (2) For version prior to 2.0
 (3) For version 2.0 onward
 (4) For version 3.00 onward
 (5) For version 0.98 onward

(Values entered at addresses **008-014** contain 3 digits between "000" and "255".) ([10] = 0)

008: ___/___/___ (days) Auto test report every ? days (between "001" and "255") (000 = disabled)

009: ___/___/___ (hours) Auto test report (between "000" and "023")

010: ___/___/___ (minutes) Auto test report (between "000" and "059")

011: ___/___/___ PGM timer setting: 001-127 for seconds and 129-255 for minutes (default 5 seconds).
 Add 128 to desired value in minutes. Ex: for 5 minutes: enter 5 + 128 = 133

014: ___/___/___ Programmer lock (147 = locked, 000 = unlocked) (default unlocked)

ESPRINT WIRING DIAGRAM

